
UART Program Examples

1. Introduction

This Application Note provides to customers C and Assembler program examples for UART.

These examples are developed for the different configuration modes of this feature.

1.1 References

- Atmel 8051 Microcontrollers Hardware Manual



**8051
Microcontrollers**

Application Note

Rev. 4346A-8051-06/04





2. C Example

2.1 Mode 1 (8 bit) with Timer1

```
/**
 * @file $RCSfile: uart_t1.c,v $
 * Copyright (c) 2004 Atmel.
 * Please read file license.txt for copyright notice.
 * @brief This file is an example to use uart with timer1.
 * UART will echo a received data.
 * This file can be parsed by Doxygen for automatic documentation
 * generation.
 * Put here the functional description of this file within the software
 * architecture of your program.
 * @version $Revision: 1.0 $ $Name: $
 */
/* @section I N C L U D E S */
#include "reg_c51.h"
char uart_data;
/**
 * FUNCTION_PURPOSE: This file set up uart in mode 1 (8 bits uart) with
 * timer 1 in mode 2 (8 bits auto reload timer).
 * FUNCTION_INPUTS: void
 * FUNCTION_OUTPUTS: void
 */
void main (void)
{
    SCON = 0x50; /* uart in mode 1 (8 bit), REN=1 */
    TMOD = TMOD | 0x20 ; /* Timer 1 in mode 2 */
    TH1 = 0xFD; /* 9600 Bds at 11.059MHz */
    TL1 = 0xFD; /* 9600 Bds at 11.059MHz */
    ES = 1; /* Enable serial interrupt*/
    EA = 1; /* Enable global interrupt */
    TR1 = 1; /* Timer 1 run */
    while(1); /* endless */
}
/**
 * FUNCTION_PURPOSE: serial interrupt, echo received data.
 * FUNCTION_INPUTS: P3.0(RXD) serial input
 * FUNCTION_OUTPUTS: P3.1(TXD) serial output
 */
void serial_IT(void) interrupt 4
{
    if (RI == 1)
    {
        /* if reception occur */
        RI = 0; /* clear reception flag for next reception */
        uart_data = SBUF; /* Read receive data */
        SBUF = uart_data; /* Send back same data on uart*/
    }
    else TI = 0; /* if emission occur */
    /* clear emission flag for next emission*/
}
```

2.2 Mode 1 (8 bit) with Timer2

```
/**
 * @file $RCSfile: uart_t2.c,v $
 * Copyright (c) 2004 Atmel.
 * Please read file license.txt for copyright notice.
 * @brief This file is an example to use uart with timer2.
 * UART will echo a received data.
 * This file can be parsed by Doxygen for automatic documentation
 * generation.
 * Put here the functional description of this file within the software
 * architecture of your program.
 * @version $Revision: 1.0 $ $Name: $
 */
/* @section I N C L U D E S */
#include "reg_c51.h"
char uart_data;
/**
 * FUNCTION_PURPOSE: This file set up uart in mode 1 (8 bits uart) with
 * timer 2 in baud rate generator mode.
 * FUNCTION_INPUTS: void
 * FUNCTION_OUTPUTS: void
 */
void main (void)
{
    SCON = 0x50; /* uart in mode 1 (8 bit), REN=1 */
    T2CON &= 0xF0; /* EXEN2=0; TR2=0; C/T2#=0; CP/RL2#=0; */
    T2CON |= 0x30; /* RCLK = 1; TCLK=1; */
    TH2=0xFF; /* init value */
    TL2=0xFD; /* init value */
    RCAP2H=0xFF; /* reload value, 115200 Bds at 11.059MHz */
    RCAP2L=0xFD; /* reload value, 115200 Bds at 11.059MHz */
    ES = 1; /* Enable serial interrupt */
    EA = 1; /* Enable global interrupt */
    TR2 = 1; /* Timer 2 run */
    while(1); /* endless */
}
/**
 * FUNCTION_PURPOSE: serial interrupt, echo received data.
 * FUNCTION_INPUTS: P3.0(RXD) serial input
 * FUNCTION_OUTPUTS: P3.1(TXD) serial output
 */
void serial_IT(void) interrupt 4
{
    if (RI == 1)
    {
        /* if reception occur */
        RI = 0; /* clear reception flag for next reception */
        uart_data = SBUF; /* Read receive data */
        SBUF = uart_data; /* Send back same data on uart*/
    }
    else TI = 0; /* if emission occur */
    /* clear emission flag for next emission*/
}
```



2.3 Mode 1 (8 bit) with internal baud rate generator

```
/**
 * @file $RCSfile: uart_int_brg.c,v $
 * Copyright (c) 2004 Atmel.
 * Please read file license.txt for copyright notice.
 * @brief This file is an example to use uart with internal baud rate
 * generator.
 * UART will echo a received data.
 * This file can be parsed by Doxygen for automatic documentation
 * generation.
 * Put here the functional description of this file within the software
 * architecture of your program.
 * @version $Revision: 1.0 $ $Name: $
 */
/* @section I N C L U D E S */
#include "reg_c51.h"
char uart_data;
/**
 * FUNCTION_PURPOSE: This file set up uart in mode 1 (8 bits uart) with
 * internal baud rate generator.
 * FUNCTION_INPUTS: void
 * FUNCTION_OUTPUTS: void
 */
void main (void)
{
    CKCON0 = 0x7F;
    SCON = 0x50; /* uart in mode 1 (8 bit), REN=1 */
    BDRCON &= 0xEE; /* BRR=0; SRC=0; */
    BDRCON |= 0x0E; /* TBCK=1; RBCK=1; SPD=1 */
    BRL=0xFD; /* 9600 Bds at 11.059MHz */
    ES = 1; /* Enable serial interrupt*/
    EA = 1; /* Enable global interrupt */
    BDRCON |= 0x10; /* Baud rate generator run*/
    while(1); /* endless */
}
/**
 * FUNCTION_PURPOSE: serial interrupt, echo received data.
 * FUNCTION_INPUTS: P3.0(RXD) serial input
 * FUNCTION_OUTPUTS: P3.1(TXD) serial output
 */
void serial_IT(void) interrupt 4
{
    if (RI == 1)
    {
        /* if reception occur */
        RI = 0; /* clear reception flag for next reception */
        uart_data = SBUF; /* Read receive data */
        SBUF = uart_data; /* Send back same data on uart*/
    }
    else TI = 0; /* if emission occur */
    /* clear emission flag for next emission*/
}
}
```

2.4 Mode 3 (8 bit) Multiprocessor communications

2.4.1 Master

```
/**
 * @file $RCSfile: uart_multiproc_master.c,v $
 *
 * Copyright (c) 2004 Atmel.
 *
 * Please read file license.txt for copyright notice.
 *
 * @brief This file is an example to use uart with timer in
 * multiprocessor mode.
 *
 * This file can be parsed by Doxygen for automatic documentation
 * generation.
 * Put here the functional description of this file within the software
 * architecture of your program.
 *
 * @version $Revision: 1.0 $ $Name: $
 */
/* @section I N C L U D E S */
#include "reg_c51.h"
char uart_data;
char exemple_send_data=0x55;
char TxOK=0;
/**
 * FUNCTION_PURPOSE: This file set up uart in mode 3 (9 bits uart) with
 * timer 1 in baud rate generator mode.
 * FUNCTION_INPUTS: P3.2(INT0)
 * FUNCTION_OUTPUTS: void
 */
void main (void)
{
    SCON = 0xF0; /* uart in mode 3 (9 bit), REN=1 */
    SADDR=0x01; /* local address */
    SADEN=0xFF; /* address mask */
    TMOD = TMOD | 0x20 ; /* Timer 1 in mode 2 */
    TH1 = 0xFD; /* 9600 Bds at 11.059MHz */
    TL1 = 0xFD; /* 9600 Bds at 11.059MHz */
    ES = 1; /* Enable serial interrupt */
    EA = 1; /* Enable global interrupt */
    TR1 = 1; /* Timer 1 run */
    while(1) /* endless */
    {
        while(P3_2); /* wait P3_2(INT0)=0 */
        while(!P3_2); /* wait P3_2(INT0)=1 */

        TB8 = 1; /* address mode */
        TxOK=1; /* set software flag */
        SBUF = 0x03; /* send slave address */
    }
}
```



```
while(TxOK);          /* wait the stop bit transmission */

TB8 = 0;              /* data mode */
TxOK=1;              /* set software flag */
SBUF = exemple_send_data; /* send data */
while(TxOK);        /* wait the stop bit transmission */
}
}
/**
 * FUNCTION_PURPOSE: serial interrupt.
 * FUNCTION_INPUTS: P3.0(RXD) serial input
 * FUNCTION_OUTPUTS: none
 */
void serial_IT(void) interrupt 4
{
    if (TI == 1)
    {
        /* if reception occur */
        TI=0;          /* clear transmission flag for next transmission */
        TxOK=0;       /* clear software transmission flag */
    }

    if (RI == 1)
    {
        /* if reception occur */
        RI = 0;       /* clear reception flag for next reception */
        if(RB8) SM2=0; /* go into data mode */
        else
        {
            uart_data = SBUF; /* Read receive data */
            SM2=1;          /* return into address mode after receive data */
        }
    }
}

/**
 * @file $RCSfile:uart_multiproc_slave.c,v $
 *
 * Copyright (c) 2004 Atmel.
 *
 * Please read file license.txt for copyright notice.
 *
 * @brief This file is an example to use uart with timer in
 * multiprocessor mode.
 * Slave will echo a received data to master.
 * This file can be parsed by Doxygen for automatic documentation
 * generation.
 * Put here the functional description of this file within the software
 * architecture of your program.
 */
```

2.4.2 Slave

```

* @version $Revision: 1.0 $ $Name: $
*/

/* @section I N C L U D E S */
#include "reg_c51.h"

char uart_data;
bit TxOK=0;
bit echo=0;

/**
 * FUNCTION_PURPOSE: This file set up uart in mode 3 (9 bits uart) with
 * timer 1 in baud rate generator mode.
 * FUNCTION_INPUTS: void
 * FUNCTION_OUTPUTS: P3.1(TXD) serial output
 */
void main (void)
{
    SCON = 0xF0; /* uart in mode 3 (9 bit), REN=1 */
    SADDR=0x03; /* local address */
    SADEN=0xFF; /* address mask */
    TMOD = TMOD | 0x20 ; /* Timer 1 in mode 2 */
    TH1 = 0xFD; /* 9600 Bds at 11.059MHz */
    TL1 = 0xFD; /* 9600 Bds at 11.059MHz */
    ES = 1; /* Enable serial interrupt */
    EA = 1; /* Enable global interrupt */
    TR1 = 1; /* Timer 1 run */

    while(1) /* endless */
    {
        while(!echo); /* wait data to echo */
        echo = 0; /* disable echo */

        TB8 = 1; /* address mode */
        TxOK=1; /* set software flag */
        SBUF = 0x01; /* send master address */
        while(TxOK); /* wait the stop bit transmission */

        TB8 = 0; /* data mode */
        TxOK=1; /* set software flag */
        SBUF = uart_data; /* send data */
        while(TxOK); /* wait the stop bit transmission */
    }
}

/**
 * FUNCTION_PURPOSE: serial interrupt, receive data to master
 * FUNCTION_INPUTS: P3.0(RXD) serial input
 * FUNCTION_OUTPUTS: none
 */

```



```
void serial_IT(void) interrupt 4
{
  if (TI == 1)
  {
    /* if reception occur */
    TI=0;          /* clear transmission flag for next transmission */
    TxOK=0;       /* clear software transmission flag */
  }

  if (RI == 1)
  {
    /* if reception occur */
    RI = 0;       /* clear reception flag for next reception */
    if(RB8) SM2=0; /* go into data mode */
    else
    {
      uart_data = SBUF; /* Read receive data */
      SM2=1;           /* return into address mode after receive data */
      /*
      echo=1;          /* enable echo */
    }
  }
}
```

2.5 SFR Register Definition

```
/*H*****
**
* NAME: reg_c51.h
*-----
-
* PURPOSE: SFR Description file for 8051 products
*         ON KEIL compiler
*****
*/

#define Sfr(x, y)  sfr x = y
#define Sbit(x, y, z)  sbit x = y^z
#define Sfr16(x,y)  sfr16 x = y

/*-----*/
/* Include file for 8051 SFR Definitions */
```


/*-----*/

/* BYTE Register */

Sfr (P0 , 0x80);

Sbit (P0_7 , 0x80, 7);

Sbit (P0_6 , 0x80, 6);

Sbit (P0_5 , 0x80, 5);

Sbit (P0_4 , 0x80, 4);

Sbit (P0_3 , 0x80, 3);

Sbit (P0_2 , 0x80, 2);

Sbit (P0_1 , 0x80, 1);

Sbit (P0_0 , 0x80, 0);

Sfr (P1 , 0x90);

Sbit (P1_7 , 0x90, 7);

Sbit (P1_6 , 0x90, 6);

Sbit (P1_5 , 0x90, 5);

Sbit (P1_4 , 0x90, 4);

Sbit (P1_3 , 0x90, 3);

Sbit (P1_2 , 0x90, 2);

Sbit (P1_1 , 0x90, 1);

Sbit (P1_0 , 0x90, 0);

Sfr (P2 , 0xA0);

Sbit (P2_7 , 0xA0, 7);

Sbit (P2_6 , 0xA0, 6);

Sbit (P2_5 , 0xA0, 5);

Sbit (P2_4 , 0xA0, 4);

Sbit (P2_3 , 0xA0, 3);

Sbit (P2_2 , 0xA0, 2);

Sbit (P2_1 , 0xA0, 1);

Sbit (P2_0 , 0xA0, 0);

Sfr (P3 , 0xB0);

Sbit (P3_7 , 0xB0, 7);

Sbit (P3_6 , 0xB0, 6);

Sbit (P3_5 , 0xB0, 5);

Sbit (P3_4 , 0xB0, 4);

Sbit (P3_3 , 0xB0, 3);

Sbit (P3_2 , 0xB0, 2);

Sbit (P3_1 , 0xB0, 1);

Sbit (P3_0 , 0xB0, 0);

Sbit (RD , 0xB0, 7);



```
Sbit (WR , 0xB0, 6);
Sbit (T1 , 0xB0, 5);
Sbit (T0 , 0xB0, 4);
Sbit (INT1 , 0xB0, 3);
Sbit (INT0 , 0xB0, 2);
Sbit (TXD , 0xB0, 1);
Sbit (RXD , 0xB0, 0);

Sfr (P4 , 0xC0);
Sbit (P4_7 , 0xC0, 7);
Sbit (P4_6 , 0xC0, 6);
Sbit (P4_5 , 0xC0, 5);
Sbit (P4_4 , 0xC0, 4);
Sbit (P4_3 , 0xC0, 3);
Sbit (P4_2 , 0xC0, 2);
Sbit (P4_1 , 0xC0, 1);
Sbit (P4_0 , 0xC0, 0);

Sfr (P5 , 0xE8);
Sbit (P5_7 , 0xE8, 7);
Sbit (P5_6 , 0xE8, 6);
Sbit (P5_5 , 0xE8, 5);
Sbit (P5_4 , 0xE8, 4);
Sbit (P5_3 , 0xE8, 3);
Sbit (P5_2 , 0xE8, 2);
Sbit (P5_1 , 0xE8, 1);
Sbit (P5_0 , 0xE8, 0);

Sfr (PSW , 0xD0);

Sbit (CY , 0xD0 , 7);
Sbit (AC , 0xD0 , 6);
Sbit (F0 , 0xD0 , 5);
Sbit (RS1 , 0xD0 , 4);
Sbit (RS0 , 0xD0 , 3);
Sbit (OV , 0xD0 , 2);
Sbit (UD , 0xD0 , 1);
Sbit (P , 0xD0 , 0);

Sfr (ACC , 0xE0);
Sfr (B , 0xF0);
Sfr (SP , 0x81);
Sfr (DPL , 0x82);
Sfr (DPH , 0x83);

Sfr (PCON , 0x87);
Sfr (CKCON0 , 0x8F);
Sfr (CKCON1 , 0xAF);
```

```

/*----- TIMERS registers -----*/
Sfr (TCON , 0x88);
Sbit (TF1 , 0x88, 7);
Sbit (TR1 , 0x88, 6);
Sbit (TF0 , 0x88, 5);
Sbit (TR0 , 0x88, 4);
Sbit (IE1 , 0x88, 3);
Sbit (IT1 , 0x88, 2);
Sbit (IE0 , 0x88, 1);
Sbit (IT0 , 0x88, 0);

Sfr (TMOD , 0x89);

Sfr (T2CON , 0xC8);
Sbit (TF2 , 0xC8, 7);
Sbit (EXF2 , 0xC8, 6);
Sbit (RCLK , 0xC8, 5);
Sbit (TCLK , 0xC8, 4);
Sbit (EXEN2 , 0xC8, 3);
Sbit (TR2 , 0xC8, 2);
Sbit (C_T2 , 0xC8, 1);
Sbit (CP_RL2, 0xC8, 0);

Sfr (T2MOD , 0xC9);
Sfr (TLO , 0x8A);
Sfr (TL1 , 0x8B);
Sfr (TL2 , 0xCC);
Sfr (TH0 , 0x8C);
Sfr (TH1 , 0x8D);
Sfr (TH2 , 0xCD);
Sfr (RCAP2L , 0xCA);
Sfr (RCAP2H , 0xCB);
Sfr (WDTRST , 0xA6);
Sfr (WDTPRG , 0xA7);

/*----- UART registers -----*/
Sfr (SCON , 0x98);
Sbit (SM0 , 0x98, 7);
Sbit (FE , 0x98, 7);
Sbit (SM1 , 0x98, 6);
Sbit (SM2 , 0x98, 5);
Sbit (REN , 0x98, 4);
Sbit (TB8 , 0x98, 3);
Sbit (RB8 , 0x98, 2);
Sbit (TI , 0x98, 1);
Sbit (RI , 0x98, 0);

Sfr (SBUF , 0x99);
Sfr (SADEN , 0xB9);

```



```
Sfr (SADDR , 0xA9);

/*----- Internal Baud Rate Generator -----*/
Sfr (BRL , 0x9A);
Sfr (BDRCON , 0x9B);

/*----- IT registers -----*/
Sfr (IEN0 , 0xA8);
Sfr (IEN1 , 0xB1);
Sfr (IPH0 , 0xB7);
Sfr (IPH1 , 0xB3);
Sfr (IPL0 , 0xB8);
Sfr (IPL1 , 0xB2);

/* IEN0 */
Sbit (EA , 0xA8, 7);
Sbit (EC , 0xA8, 6);
Sbit (ET2 , 0xA8, 5);
Sbit (ES , 0xA8, 4);
Sbit (ET1 , 0xA8, 3);
Sbit (EX1 , 0xA8, 2);
Sbit (ET0 , 0xA8, 1);
Sbit (EX0 , 0xA8, 0);

/*----- PCA registers -----*/
Sfr (CCON , 0xD8);
Sfr (CMOD , 0xD9);
Sfr (CH , 0xF9);
Sfr (CL , 0xE9);
Sfr (CCAP0H , 0xFA);
Sfr (CCAP0L , 0xEA);
Sfr (CCAPM0 , 0xDA);
Sfr (CCAP1H , 0xFB);
Sfr (CCAP1L , 0xEB);
Sfr (CCAPM1 , 0xDB);
Sfr (CCAP2H , 0xFC);
Sfr (CCAP2L , 0xEC);
Sfr (CCAPM2 , 0xDC);
Sfr (CCAP3H , 0xFD);
Sfr (CCAP3L , 0xED);
Sfr (CCAPM3 , 0xDD);
Sfr (CCAP4H , 0xFE);
Sfr (CCAP4L , 0xEE);
Sfr (CCAPM4 , 0xDE);
/* CCON */
```

```

Sbit (CF , 0xD8, 7);
Sbit (CR , 0xD8, 6);

Sbit (CCF4 , 0xD8, 4);
Sbit (CCF3 , 0xD8, 3);
Sbit (CCF2 , 0xD8, 2);
Sbit (CCF1 , 0xD8, 1);
Sbit (CCF0 , 0xD8, 0);

/*----- T W I registers -----*/
Sfr ( SSSCON , 0x93);
Sfr ( SSSCS , 0x94);
Sfr ( SSSDAT , 0x95);
Sfr ( SSSADR , 0x96);
Sfr ( PI2, 0xF8);
Sbit (PI2_1 , 0xF8, 1);
Sbit (PI2_0 , 0xF8, 0);

/*----- OSC control registers -----*/
Sfr ( CKSEL , 0x85 );
Sfr ( OSCCON , 0x86 );
Sfr ( CKRL , 0x97 );

/*----- Keyboard control registers -----*/
Sfr ( KBLS , 0x9C );
Sfr ( KBE , 0x9D );
Sfr ( KBF , 0x9E );
/*----- SPI -----*/
Sfr ( SPCON, 0xC3 );
Sfr ( SPSTA, 0xC4 );
Sfr ( SPDAT, 0xC5 );

/*----- Misc -----*/
Sfr( AUXR , 0x8E);
Sfr ( AUXR1, 0xA2);
Sfr ( FCON, 0xD1);

/*----- E data -----*/

Sfr ( EECON, 0xD2 );

```



3. Assembler 51 Examples

3.1 UART

Mode 1 (8 bit) with Timer1

```
$INCLUDE (reg_c51.INC)

org 000h
ljmp begin

org 23h
ljmp serial_IT

;/**
; * FUNCTION_PURPOSE: This file set up uart in mode 1 (8 bits uart) with
; * timer 1 in mode 2 (8 bits auto reload timer).
; * FUNCTION_INPUTS: void
; * FUNCTION_OUTPUTS: void
; */
org 0100h

begin:
MOV SCON, #50h; /* uart in mode 1 (8 bit), REN=1 */
ORL TMOD, #20h; /* Timer 1 in mode 2 */
MOV TH1, #0FDh; /* 9600 Bds at 11.059MHZ */
MOV TL1, #0FDh; /* 9600 Bds at 11.059MHZ */
SETB ES; /* Enable serial interrupt*/
SETB EA; /* Enable global interrupt */
SETB TR1; /* Timer 1 run */

JMP $; /* endless */

;/**
; * FUNCTION_PURPOSE: serial interrupt, echo received data.
; * FUNCTION_INPUTS: P3.0(RXD) serial input
; * FUNCTION_OUTPUTS: P3.1(TXD) serial output
; */
serial_IT:
JNB RI,EMIT_IT ; test if it is a reception
CLR RI ; clear reception flag for next reception
MOV A,SBUF ; read data from uart
MOV SBUF,A ; write same data to uart
LJMP END_IT
EMIT_IT:
CLR TI ; clear transmission flag for next transmission

END_IT:
RETI

end
```

3.2 Mode 1 (8 bit) with Timer2

```
$INCLUDE (reg_c51.INC)

org 000h
ljmp begin

org 23h
ljmp serial_IT

;/**
; * FUNCTION_PURPOSE: This file set up uart in mode 1 (8 bits uart) with
; * timer 2 in baud rate generator mode.
; * FUNCTION_INPUTS: void
; * FUNCTION_OUTPUTS: void
; */
org 0100h

begin:
MOV SCON,#50h; /* uart in mode 1 (8 bit), REN=1 */
ANL T2CON,#0F0h; /* EXEN2=0; TR2=0; C/T2#=0; CP/RL2#=0; */
ORL T2CON,#30h; /* RCLK = 1; TCLK=1; */
MOV TH2,#0FFh; /* init value */
MOV TL2,#0FDh; /* init value */
MOV RCAP2H,#0FFh; /* reload value, 115200 Bds at 11.059MHz */
MOV RCAP2L,#0FDh; /* reload value, 115200 Bds at 11.059MHz */
SETB ES; /* Enable serial interrupt */
SETB EA; /* Enable global interrupt */
SETB TR2; /* Timer 2 run */

JMP $; /* endless */

;/**
; * FUNCTION_PURPOSE: serial interrupt, echo received data.
; * FUNCTION_INPUTS: P3.0(RXD) serial input
; * FUNCTION_OUTPUTS: P3.1(TXD) serial output
; */
serial_IT:
JNB RI,EMIT_IT ; test if it is a reception
CLR RI ; clear reception flag for next reception
MOV A,SBUF ; read data from uart
MOV SBUF,A ; write same data to uart
LJMP END_IT
EMIT_IT:
CLR TI ; clear transmission flag for next transmission

END_IT:
RETI

end
```



3.3 Mode 1 (8 bit) with internal baud rate generator

```
$INCLUDE (reg_c51.INC)

org 000h
ljmp begin

org 23h
ljmp serial_IT

;/**
; * FUNCTION_PURPOSE: This file set up uart in mode 1 (8 bits uart) with
; * internal baud rate generator.
; * FUNCTION_INPUTS: void
; * FUNCTION_OUTPUTS: void
; */
org 0100h

begin:
MOV SCON,#50h; /* uart in mode 1 (8 bit), REN=1 */
ANL BDRCON,#0EEh; /* BRR=0; SRC=0; */
ORL BDRCON,#0Eh; /* TBCK=1;RBCK=1; SPD=1 */
MOV BRL,#0FDh; /* 9600 Bds at 11.059MHz */
SETB ES; /* Enable serial interrupt*/
SETB EA; /* Enable global interrupt */
ORL BDRCON,#10h; /* Baud rate generator run*/

JMP $; /* endless */

;/**
; * FUNCTION_PURPOSE: serial interrupt, echo received data.
; * FUNCTION_INPUTS: P3.0(RXD) serial input
; * FUNCTION_OUTPUTS: P3.1(TXD) serial output
; */
serial_IT:
JNB RI,EMIT_IT ; test if it is a reception
CLR RI ; clear reception flag for next reception
MOV A,SBUF ; read data from uart
MOV SBUF,A ; write same data to uart
LJMP END_IT
EMIT_IT:
CLR TI ; clear transmission flag for next transmission

END_IT:
RETI

end
```


3.4 Mode 3 (9 bit) Multiprocessor Communications

3.4.1 Master

```
$INCLUDE (reg_c51.INC)
TxOK BIT 21H; software flag

org 000h
ljmp begin

org 23h
ljmp serial_IT

;/**
; * FUNCTION_PURPOSE: This file set up uart in mode 3 (9 bits uart) with
; * timer 1 in baud rate generator mode.
; * FUNCTION_INPUTS: P3.2(INT0)
; * FUNCTION_OUTPUTS: void
; */
org 0100h

begin:
MOV SCON, #0F0h; /* uart in mode 3 (9 bit), REN=1 */
MOV SADDR,#01h; /* local address */
MOV SADEN,#0FFh; /* address mask */
ORL TMOD, #20h; /* Timer 1 in mode 2 */
MOV TH1, #0FDh; /* 9600 Bds at 11.059MHz */
MOV TL1, #0FDh; /* 9600 Bds at 11.059MHz */
SETB ES; /* Enable serial interrupt*/
SETB EA; /* Enable global interrupt */
SETB TR1; /* Timer 1 run */

loop:
JB P3.2,$; /* wait P3_2(INT0)=0 */
JNB P3.2,$; /* wait P3_2(INT0)=1 */

SETB TB8; /* address mode */
SETB TxOK; /* set software flag */
MOV SBUF,#03h; /* send slave address */
JB TxOK,$; /* wait the stop bit transmission */
CLR TB8; /* data mode */
SETB TxOK; /* set software flag */
MOV SBUF,#55h; /* send data example */
JB TxOK,$; /* wait the stop bit transmission */

SJMP loop

;/**
; * FUNCTION_PURPOSE: serial interrupt,
; * FUNCTION_INPUTS: P3.0(RXD) serial input
```



```
; * FUNCTION_OUTPUTS: none
; */
serial_IT:
    JNB     TI,END_Test_TI
    CLR     TI
    CLR     TxOK
END_Test_TI:

    JNB     RI,END_Test_RI;    /* test if it is a reception */
    CLR     RI;                /* clear reception flag for next reception */
    JNB     RB8,address_mode
    CLR     SM2;                /* go into data mode */
    LJMP   END_Test_RB8
address_mode:
    MOV     A,SBUF;            /* Read receive data */
    SETB    SM2;                /* return into address mode after receive data
*/
    MOV     P2,A
END_Test_RB8:
END_Test_RI:
    RETI

end
```

3.4.2 Slave

```
$INCLUDE    (reg_c51.INC)
echo BIT 20H; echo enable bit
TxOK BIT 21H; software flag

org 000h
ljmp begin

org 23h
ljmp serial_IT

/**
 * FUNCTION_PURPOSE: This file set up uart in mode 3 (9 bits uart) with
 * timer 1 in baud rate generator mode.
 * FUNCTION_INPUTS: void
 * FUNCTION_OUTPUTS: void
 */
org 0100h
begin:
    MOV SCON, #0F0h; /* uart in mode 3 (9 bit), REN=1 */
    MOV SADDR,#03h; /* local address */
    MOV SADEN,#0FFh; /* address mask */
    ORL TMOD, #20h; /* Timer 1 in mode 2 */
    MOV TH1, #0FDh; /* 9600 Bds at 11.059MHz */
    MOV TL1, #0FDh; /* 9600 Bds at 11.059MHz */
    SETB ES; /* Enable serial interrupt*/
```

```

SETB EA;          /* Enable global interrupt */
SETB TR1;        /* Timer 1 run */
loop:
    JNB  echo,$;          /* wait data to echo */
    CLR  echo ;          /* disable echo */
    SETB TB8;           /* address mode */
    SETB TxOK;          /* set software flag */
    MOV  SBUF,#01h;      /* send master address */
    JB   TxOK,$;         /* wait the stop bit transmission */
    CLR  TB8;           /* data mode */
    SETB TxOK;          /* set software flag */
    MOV  SBUF,A;         /* send data */
    JB   TxOK,$;         /* wait the stop bit transmission */
LJMP   loop

;/**
; * FUNCTION_PURPOSE: serial interrupt, echo receive data to master
; * FUNCTION_INPUTS: P3.0(RXD) serial input
; * FUNCTION_OUTPUTS: none
; */
serial_IT:
    JNB  TI,END_Test_TI; /* if reception occur */
    CLR  TI;             /* clear transmission flag for next transmission */
    CLR  TxOK;           /* clear software transmission flag */
END_Test_TI:
    JNB  RI,END_Test_RI; /* test if it is a reception */
    CLR  RI;             /* clear reception flag for next reception */

    JNB  RB8,address_mode
    CLR  SM2;            /* go into data mode */
    LJMP END_Test_RB8
address_mode:
    MOV  A,SBUF;         /* Read receive data */
    SETB SM2;           /* return into address mode after receive data */
    SETB echo
END_Test_RB8:
END_Test_RI:
    RETI

end

```



3.5 SFR Register Definition

```
$SAVE
$NOLIST

P0      DATA    80H
TCONDATA88H
;--- TCON Bits ---
TF1     BIT      8FH
TR1     BIT      8EH
TF0     BIT      8DH
TR0     BIT      8CH
IE1     BIT      8BH
IT1     BIT      8AH
IE0     BIT      89H
IT0     BIT      88H

P1      DATA    90H

SCON    DATA    98H
;--- SCON Bits ----
SM0     BIT      9FH
SM1     BIT      9EH
SM2     BIT      9DH
REN     BIT      9CH
TB8     BIT      9BH
RB8     BIT      9AH
TI      BIT      99H
RI      BIT      98H

P2      DATA    0A0H
IEN0    DATA    0A8H
;--- IEN0 Bits -----
EA      BIT0AFH
EC      BIT0AEH
ET2     BIT0ADH
ES      BIT0ACH
ET1     BIT0ABH
EX1     BIT0AAH
ET0     BIT0A9H
EXO     BIT0A8H

P3      DATA    0B0H
;--- P3 Bits -----
RD      BIT      0B7H
WR      BIT      0B6H
T1      BIT      0B5H
T0      BIT      0B4H
INT1    BIT      0B3H
INT0    BIT      0B2H
```

TXD BIT 0B1H
RXD BIT 0B0H

P4 DATA 0C0H
P5 DATA 0E8H

IPLODATA0B8H
;--- IPL0 Bits -----
PPCL BIT0BEH
PT2L BIT0BDH
PSL BIT0BCH
PT1L BIT0BBH
PX1L BIT0BAH
PT0L BIT0B9H
PX0LBIT0B8H

T2CON DATA 0C8H
;--- T2CON bits ----
TF2 BIT 0CFH
EXF2 BIT 0CEH
RCLK BIT 0CDH
TCLK BIT 0CCH
EXEN2 BIT 0CBH
TR2 BIT 0CAH
C_T2 BIT 0C9H
CP_RL2 BIT 0C8H

PSW DATA 0D0H
;--- PSW bits -----
CY BIT 0D7H
AC BIT 0D6H
F0 BIT 0D5H
RS1 BIT 0D4H
RS0 BIT 0D3H
OV BIT 0D2H
P BIT 0D0H

CCONDATA0D8H
;--- CCON bits -----
CF BIT 0DFH
CR BIT 0DEH
CCF4 BIT 0DCH
CCF3 BIT 0DBH
CCF2 BIT 0DAH
CCF1 BIT 0D9H
CCF0 BIT 0D8H

ACC DATA 0E0H



```
B          DATA    0F0H

SP         DATA    81H
DPL        DATA    82H
DPH        DATA    83H
PCON       DATA    87H

TMOD       DATA    89H
TL0        DATA    8AH
TL1        DATA    8BH
TH0        DATA    8CH
TH1        DATA    8DH
AUXRDATA08EH
CKCON0DATA08Fh

SBUF       DATA    99H
;-- Baud Rate generator
BRL        DATA09AH
BDRCON    DATA 09BH
;--- Keyboard
KBLSDATA09CH
KBEDATA09DH
KBFDATA09EH

;--- Watchdog timer
WDRSTDATA0A6H
WDTPRG    DATA0A7H

SADDRDATA0A9H
CKCON1DATA0AFH

IEN1DATA0B1H
IPL1DATA0B2H
IPH1DATA0B3H
IPH0DATA0B7H

SADENDATA0B9H

T2MODDATA    0C9h
```

```
RCAP2L DATA 0CAH
RCAP2H DATA 0CBH
TL2 DATA 0CCH
TH2 DATA 0CDH
```

```
CMODDATA0D9H
CCAPM0DATA0DAH
CCAPM1DATA0DBH
CCAPM2DATA0DCH
CCAPM3DATA0DDH
CCAPM4DATA0DEH
```

```
CHDATA0F9H
CCAP0HDATA0FAH
CCAP1HDATA0FBH
CCAP2HDATA0FCH
CCAP3HDATA0FDH
CCAP4HDATA0FEH
```

```
CLDATA0E9H
CCAP0LDATA0EAH
CCAP1LDATA0EBH
CCAP2LDATA0ECH
CCAP3LDATA0EDH
CCAP4LDATA0EEH
```

```
; SPI
SPCON DATA 0C3H
SPSTA DATA 0C4H
SPDAT DATA 0C5H
```

```
; TWI
PI2DATA 0F8h
SSCONDATA093H
SSCSDATA094H
SSDATDATA095H
SSADRDATA096H
PI2_OBIT0F8H
PI2_1BIT0F9H
```

```
; Clock Control
OSCONDATA086H
CKSELDATA085H
CKRLDATA097H
```

```
;MISC
AUXR1DATA0A2H
```



```
; Flash control  
FCON DATA 0D1H
```

```
;EEData  
EECONDATA0D2H
```

```
$RESTORE
```


Table of Contents

Introduction.....	1
References	1
C Example.....	2
Mode 1 (8 bit) with Timer1.....	2
Mode 1 (8 bit) with Timer2.....	3
Mode 1 (8 bit) with internal baud rate generator	4
Mode 3 (8 bit) Multiprocessor communications	5
Master.....	5
Slave	6
SFR Register Definition	8
Assembler 51 Examples.....	14
UART	
Mode 1 (8 bit) with Timer1	14
Mode 1 (8 bit) with Timer2.....	15
Mode 1 (8 bit) with internal baud rate generator	16
Mode 3 (9 bit) Multiprocessor Communications	17
Master 17	
Slave 18	
SFR Register Definition	20



Atmel Corporation

2325 Orchard Parkway
San Jose, CA 95131
Tel: 1(408) 441-0311
Fax: 1(408) 487-2600

Regional Headquarters

Europe

Atmel Sarl
Route des Arsenalux 41
Case Postale 80
CH-1705 Fribourg
Switzerland
Tel: (41) 26-426-5555
Fax: (41) 26-426-5500

Asia

Room 1219
Chinachem Golden Plaza
77 Mody Road Tsimshatsui
East Kowloon
Hong Kong
Tel: (852) 2721-9778
Fax: (852) 2722-1369

Japan

9F, Tonetsu Shinkawa Bldg.
1-24-8 Shinkawa
Chuo-ku, Tokyo 104-0033
Japan
Tel: (81) 3-3523-3551
Fax: (81) 3-3523-7581

Atmel Operations

Memory

2325 Orchard Parkway
San Jose, CA 95131
Tel: 1(408) 441-0311
Fax: 1(408) 436-4314

Microcontrollers

2325 Orchard Parkway
San Jose, CA 95131
Tel: 1(408) 441-0311
Fax: 1(408) 436-4314

La Chanterrie
BP 70602
44306 Nantes Cedex 3, France
Tel: (33) 2-40-18-18-18
Fax: (33) 2-40-18-19-60

ASIC/ASSP/Smart Cards

Zone Industrielle
13106 Rousset Cedex, France
Tel: (33) 4-42-53-60-00
Fax: (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd.
Colorado Springs, CO 80906
Tel: 1(719) 576-3300
Fax: 1(719) 540-1759

Scottish Enterprise Technology Park
Maxwell Building
East Kilbride G75 0QR, Scotland
Tel: (44) 1355-803-000
Fax: (44) 1355-242-743

RF/Automotive

Theresienstrasse 2
Postfach 3535
74025 Heilbronn, Germany
Tel: (49) 71-31-67-0
Fax: (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd.
Colorado Springs, CO 80906
Tel: 1(719) 576-3300
Fax: 1(719) 540-1759

Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom

Avenue de Rochepleine
BP 123
38521 Saint-Egreve Cedex, France
Tel: (33) 4-76-58-30-00
Fax: (33) 4-76-58-34-80

e-mail

literature@atmel.com

Web Site

<http://www.atmel.com>

Disclaimer: Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

© Atmel Corporation 2004. All rights reserved. Atmel® and combinations thereof are the registered trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be the trademarks of others.



Printed on recycled paper.

4346A-8051-06/04

/xM